

SPLIT

<b>DART AEROSPACE LTD</b>	<b>Work Order:</b>	<b>23993 B</b>
<b>Description: Clevis</b>	<b>Part Number:</b>	<b>B67-43001-125</b>
<b>Dwg: B67-43001 Rev. B page 34</b>	<b>Qty:</b>	<b>Page 1 of 1</b>

Step	Location	Procedure	By	Date	Qty
1	DC	Issue Traveler	CL	05-08-08	20
2	MC	Turn as per Folio FA & Dwg B67-43001 Material: 6061-T6 Bar Ø1.00 (QQ-A-200/8 or QQ-A-225/8) (M6061T6R1.000). Folio Rev: <del>110147</del> Dwg Rev: <del>110147</del> Identify for B67-43001-125 Issue P.2 Batch: 2008449	CL	05-08-09	20
3	<del>QC2</del> RG	Inspect parts as they come off the machine Identify as B67-43001-125 Receive transport	CL	05-08-09	20
4	MM	Mill as per Dwg B67-43001 N/A u			
5	<del>QC2</del>	Inspect parts as they come off the machine N/A u			
6	<del>QC2</del> 6	Second check inspect level 6		05-08-08	20
7	MM	Deburr if applicable		05-08-08	20
8	FP	Chemical Conversion Coat as per QSI 005 4.1	ML	05-08-16	20
9	FP	Powder Coat Green Sandtex (Ref: 4.3.5.8) as per QSI 005 4.3 Mask Ø0.880"			
10	QC3	Inspect Powder Coat		05-10-06	20
11	ST	Identify and Stock	CL	05/10/06	15
12	AC	Cost / part: 18.15	SAC	05-10-07	15
13	DC	Close W/O 18.15 Inspect Level 21	CL	05/10/07	15

Rev	Date	Change	Revised By	Approved
A	05.08.26	New issue	KJ/JLM	

PRELIMINARY ISSUE